Freescale Semiconductor
User Guide

SLK0101UG
Rev. 0, 9/2006

Application Module Student Learning Kit Users Guide featuring the Freescale MC9S12C32

For use with the following part numbers:
CSM-12C32
APS12C32SLK
PBS12C32SLK

© Freescale Semiconductor, Inc., 2006. All rights reserved.

freescale™
semiconductor

CONTENTS

CAUTIONARY NOTES **4**

FEATURES **5**

REFERENCES **6**

INTRODUCTION **7**

GETTING STARTED **7**

OPERATION **7**

POWER 8

PWR *8*

CONNECTOR J1 ..... *8*

PWR_SEL JUMPER *8*

RESET SWITCH 9

LOW-VOLTAGE DETECT 9

TIMING 9

COMMUNICATIONS 9

COM CONNECTOR *10*

CONNECTOR J1 ..... *11*

USER OPTIONS 11

SWITCHES *11*

LED'S *12*

DEVELOPMENT SUPPORT **12**

ASCII MONITOR OPERATION 12

ASCII MONITOR MEMORY MAP *12*

MONITOR COMMANDS *13*

INTERRUPT SUPPORT *13*

INTERRUPT VECTOR TABLE *14*

SERIAL MONITOR OPERATION 15

SERIAL MONITOR MEMORY MAP *15*

BDM_PORT HEADER 16

FIGURES

Figure 1: PWR_SEL 8
Figure 2: COM Connector 10
Figure 3: MCU_PORT Connector 11
Figure 4: BDM_PORT 16

TABLES

Table 1: Serial COM Signals 10
Table 2: User Option Jumper Settings 11
Table 4: Monitor Commands 13
Table 5: Monitor Memory Map 12
Table 6: MON12 Interrupt Vector Table 14
Table 7: Serial Monitor Memory Map 15

REVISION

August 25, 2006	A	Initial release