

Saturation of Moist Air

- Clausius-Clapeyron equation at dew point

$$\frac{dp}{dT} = \frac{L_v}{T_0} \quad (4.18)$$

$$\frac{dp}{dT} = \frac{L_v p}{R_v T^2} \quad (4.19)$$

$$\frac{d(\ln p)}{dT} = \frac{L_v}{R_v T^2} \quad (6.18)$$

$$v_v = \frac{R_v T}{p}$$

$$\frac{dp}{p} = \frac{L_v}{R_v T^2} dT$$

$$d \ln p = \frac{L_v}{R_v T^2} dT$$

$$\frac{d \ln p}{dT} = \frac{L_v}{R_v T^2}$$

Clausius Clapeyron

- Recall by integration between two temperatures we had

$$\int_{T_1}^{T_2} d(\ln p) = \int_{T_1}^{T_2} \frac{L_v}{R_v T^2} dT \quad (4.21)$$

we find

$$\ln \frac{p_2}{p_1} = -\frac{L_v}{R_v} \left(\frac{1}{T_2} - \frac{1}{T_1} \right) \quad (4.22)$$

or

$$p_2 = p_1 \exp \left[-\frac{L_v}{R_v} \left(\frac{1}{T_2} - \frac{1}{T_1} \right) \right] \quad (4.23)$$

Dewpoint and Humidity

- Integrating from ambient to saturation

$$\ln \frac{e_s}{e} = -\ln N = \frac{L_v}{R_v} \left(\frac{1}{T_0} - \frac{1}{T} \right)$$

or equivalently

$$N = \exp \left[-\frac{L_v}{R_v} \left(\frac{T - T_0}{T T_0} \right) \right] \quad (6.19)$$

- Dew point depression ($T - T_D$)





Figure 6.2 Dew-point depression. As the relative humidity increases, the difference between the ambient temperature and the dew-point temperature (i.e., the dew-point depression) decreases. As the ambient temperature decreases, the dew-point depression becomes less sensitive to changes in the relative humidity.



Cumulus Cloud Base Altitude Calculator

$$\text{Cloud Base Altitude} = \left(\left(\frac{\text{temperature} - \text{dew point}}{4.5} \right) * 1000 \right) + \text{measurment station altitude}$$

Assumes:

The rate at which air cools as it rises is averaged at 5.5°F per 1000 feet

The dew point also decreases at about 1.0°F over the same distance.

<http://www.casestwork.com/calcloudbasecalc.html>

Lecture Ch. 6b

- Moist adiabatic ascent of air
- Equivalent temperature
- Aerological diagrams

Curry and Webster, Ch. 6

For Tuesday: Read Ch. 7 (look at but don't solve Prob. 3)

Equivalent Potential Temperature

- Accounts for liquid water heating

$$\theta_e = \theta \exp\left(\frac{L_1 w_s}{c_{pd} T}\right) \quad (6.48)$$




Figure 6.7. Moist adiabatic ascent of air as a function of height above the cloud base and cloud base temperature. (A. M. Curry, 1989.)




Figure 6.8. Moist adiabatic ascent of a parcel.

the parcel. Thus the initial state may be proportional to the initial temperature or to $p^{1/\gamma}$ (the latter diagram). The former has the advantage that the slope of the diagram is proportional to the initial state. Below the advent of computers,




Figure 6.9. Determination of w , w_s , and T_e from the vertical profiles of temperature and dew-point temperature.




Figure 6.10. Moist adiabatic ascent of a parcel. The parcel initially ascends adiabatically along the constant potential temperature line that passes through $(T_0, 1000 \text{ hPa})$. As the parcel ascends, the saturation mixing ratio decreases as the moist adiabatic mixing ratio remains the same. At the point at which the moist mixing ratio of the parcel is equal to the saturation mixing ratio, the parcel becomes saturated. Further lifting of the parcel occurs along the moist adiabatic that passes through point (T_1, p_1) .

$$\theta_e = T_1 \left(\frac{p_0}{p_1}\right)^{\kappa_e}$$